

Short Work Piece Clamp for Half-blind Dovetails

- Aux Clamping Surface 1 is placed against left side stop
- Rabbeted width is equal to work piece width plus 1/16"
- Work piece is placed in the rabbeted area
- Compression split is 1/8" wide
- Clamp bar area is placed under rear clamp
- "C" Clamp used to compress clamping surfaces 1 & 2 against work piece
- Attach C Clamp at points A & B, underneath work piece

